# Parts Catalogue



# **DRP20**Reversible Plate

Engine: Honda GX 160 - CARB Phase III



No. DL00825607 | 2023-02-15

© 2023 Dynapac GmbH

Your Partner on the Road Ahead

# **General information**

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability. Any unauthorized use or copying of the contents or any part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers, and drawings.

#### Instructions for use

This spare parts list contains no safety regulations and is merely intended to assist in the ordering of spare parts.


For information about operating, servicing, or repairing, the relevant Safety and operating instructions must be consulted at all costs.

Please observe the safety instructions listed in the relevant Safety and operating instructions!

Service, repair and wear part kits
Service, repair and wear part kits
Service, repair and wear part kits
4812217845 Repair kit, shock-absorber
4812217844 Repair kit, transmission
4812217510 Repair kit, exciter unit
4812217843 Repair kit, throttle unit
4812217512 Seal kit, exciter unit
DL92492442_01 Service kit
Refurbishing kits
4812217846 Refurbishing kit - covering
4812217847 Refurbishing kit - decals
Color Dynapac-Light
Field kits
DL92401009_00 X5-Synthetic plate
DL92401010 T94-Transport wheels,failsave
Lubricants
Lubricants and operating substances
40 F v 1 v
10 Engine   DL69200056_00_010_DRP20 Engine / Fitting Parts 2
25_55_55_55_55_556_577 tuning 1 drift
Engine / Fitting Parts
DL05747045_1001E Engine Parts List
DLMOT019729_00 Crankcase
DLMOT019730_00 Front Cover
DLMOT019731_00 Cylinder Head
DLMOT019732_00 Camshaft
DLMOT019733_00 Crankshaft And Piston
DLMOT019734_00 Fuel Tank
DLMOT019735_00 Dry Air Filter
DLMOT019736_00 Throttle Control
DLMOT019737_00 Silencer
DLMOT019738_00 Recoil Starter
DLMOT019739_00 Covering
DLMOT019740_00 Contact Breaker/Ign.Coil
DLMOT019741_00 Carburetor
DL92410086_00 Engine Carrier
DL92410702_00 Engine
DLEA002611_00 Centrifugal Clutch
20 Transmission   DL69200056_00_020_DRP20 Power Transmission / Actuation 6
Power Transmission / Actuation
DL69110044_02 Travel Actuation
DL69100045_01 Throttle Control
DL69110170_05 Steering rod head
DL69110222_02 Detent, assembled
DLEA002305_00 Actuat.Cable Throttle Re
50 Frame
DL69200056_00_050_DRP20 Frame with Attachment Parts
Frame with Attachment Parts
DL92410087_00 Steering Handle
DL92410577_00 Protection hood
DL69120833_00 Single-point suspens.,assembled

5 Plate	
DL69200056_00_065_DRP20 Plate / Foot	87
Plate / Foot	
DL69020045_02 Base Plate	89
DL69020834_00 Base plate,assembled	94
00 Accessories	
DL69200056_00_100_DRP20 Accessories	96
Accessories	
DL92410088_01 Decals	98
10 Options	
DL69200056_00_110_DRP20 Special Equipment	100
Special Equipment	
DL92400106_01 AD1-Protection hood	102
DL92401009_00 X5-Synthetic plate	22
DL92400107_00 T94-Transport wheels,failsave	
DL69070308_00 Central electric, assembled	109
DL92401032_00 AZ4-Operating hourmeter	111

Service, repair and wear part kits Service, repair and wear part kits











Item	Part No.	Qty	Name	SN INFO
1			Service, repair and wear part kits	
1.1	4812217845	1	Repair kit, shock-absorber	
1.2	4812217844	1	Repair kit, transmission	
1.3	4812217510	1	Repair kit, exciter unit	
1.4	4812217843	1	Repair kit, throttle unit	SN - from 101924661001 to 101924661020
1.5	4812217512	1	Seal kit, exciter unit	
1.6	DL92492442	1	Service kit	
2			Refurbishing kit	
2.1	4812217846	1	Refurbishing kit - covering	
2.2	4812217847	1	Refurbishing kit - decals	
2.3	-		Color Dynapac-Light	
3			Field kit	
3.1	DL92401009	1	X5-Synthetic plate	
3.2	DL92401010	1	T94-Transport wheels,failsave	
4	PNNA		Lubricants and operating substances	


Service, repair and wear part kits 4812217845 Repair kit, shock-absorber






Item	Part No.	Qty	Name	SN INFO
KIT	4812217845	1	Repair kit, shock-absorber	
1	DL06127525	4	Rubber buffer	
2	DL69030240	4	Shim	
3	DL07231211	4	Socket-head cap screw	
4	DL08511324	4	Washer	
5	DL08241217	4	Domed cap nut	
6	DL08752130	4	Spring washer	
7	DL06143712	4	Stop buffer	
8	DL06140945	1	Stop buffer	
9	DL06147115	1	Stop buffer	
10	DL08141620	2	Hexagon nut	
11	DL07140824	2	Hexagon bolt	
12	DL08510817	2	Washer	
13	DL06142915	1	Stop buffer	
14	DL08752084	1	Spring washer	
15	DL08110813	1	Hexangon nut	
16	DL08131621	1	Safety nut	
17	DL08511730	2	Washer	
18	DL06151711	2	Rubber bush	
19	DL06140985	1	Stop buffer	

Service, repair and wear part kits 4812217844 Repair kit, transmission




Item	Part No.	Qty	Name	SN INFO
KIT	4812217844	1	Repair kit, transmission	
1	DL05650116	1	Centrifugal clutch	
2	DL92410583	1	V-belt	
3	DL69040261	1	Washer	
4	DL08510817	1	Washer	
5	DL07230838	1	Socket-head cap screw	
6	DL69020479	1	V-belt pulley	
7	DL07230827	2	Socket-head cap screw	
8	DL09120862	1	Pin,cylindric	
9	DL69020304	2	Shim	
10	DL69020480	1	V-belt pulley	
11	DL07230834	2	Socket-head cap screw	

Service, repair and wear part kits 4812217510 Repair kit, exciter unit




Item	Part No.	Qty	Name	SN INFO
KIT	4812217510	1	Repair kit, exciter unit	
1	DL05222263	1	Cylinder roller bearing	
2	DL69020747	1	Bushing	
3	DL09223700	1	Circlip,internal	
4	DL05114030	1	Ball bearing,grooved	
5	DL05428122	1	Inner ring	
6	DL06220803	1	Loop ring	
7	DL05222264	3	Cylinder roller bearing	

Service, repair and wear part kits 4812217843 Repair kit, throttle unit




Item	Part No.	Qty	Name	SN INFO
KIT	4812217843	1	Repair kit, throttle unit	SN - from 101924661001 to 101924661020
1	DL05561594	1	Throttle control	
2	DL07320508	2	Countersunk screw	
3	DL08510511	2	Washer	
4	DL08240510	2	Domed cap nut	

Service, repair and wear part kits 4812217512 Seal kit, exciter unit



Item	Part No.	Qty	Name	SN INFO
KIT	4812217512	1	Seal kit, exciter unit	
1	DL06222657	1	Loop ring	
2	DL06220852	1	Loop ring	
3	DL06220803	3	Loop ring	


Service, repair and wear part kits DL92492442\_01 Service kit



194.08


Item	Part No.	Qty	Name	SN INFO
0	DL92492442	1	Service kit	
1	DL05747215	1	Element	
2	DL05748603	1	Gasket, oil dip stick	
3	DL05747125	1	Valve cover gasket	
4	DL92410583	1	V-belt	
5	DL05747161	1	Filter,fuel	
6	DL05747188	1	Loop ring	
7	DL05546131	1	Screw plug with seal	
8	DL09331098	1	Sealing ring	
9	DL07611215	1	Screw plug	
10	DL07611010	1	Screw plug	
11	DL05747930	1	Spark plug	
12	DL05748578	1	Starter rope	
13	DL07230834	2	Socket-head cap screw	
14	DL83403043	1	Gasket	

Refurbishing kits 4812217846 Refurbishing kit - covering




Item	Part No.	Qty	Name	SN INFO
KIT	4812217846	1	Refurbishing kit - covering	
1	DL69120853	1	Cover plate	
2	DL07140641	4	Hexagon bolt	
3	DL08510612	8	Washer	
4	DL69120353	1	Strip steel	
5	DL08130611	4	Safety nut	
6	DL69120778	1	Cover plate	
7	DL69120440	1	Strip steel	

Refurbishing kits 4812217847 Refurbishing kit - decals




Item	Part No.	Qty	Name	SN INFO
KIT	4812217847	1	Refurbishing kit - decals	
1	DL92410302	1	Decal	
2	DL00832675	1	Decal,operation	
3	DL00834353	1	Decal,operation	
4	DL00830085	1	Decal,operation	
5	DL00832654	1	Decal,indication	
6	DL92410421	1	Type designation	
7	DL00832900	1	Decal,indication	
8	DL00832901	1	Decal,indication	
9	DL00833653	1	Decal,indication	
10	DL00831294	1	Decal,maintenance instr.	
11	DL00833833	1	Decal,indication	
12	DL00833968	1	Warning sign	

Refurbishing kits Color Dynapac-Light



Item	Part No.	Qty	Name	SN INFO
1	4812215512	1	Dynapac color, red	
2	4812215516	1	Dynapac color, white	
3	4812071005	1	Dynapac color, grey	


Field kits DL92401009\_00 X5-Synthetic plate



165.01


Item	Part No.	Qty	Name	SN INFO
KIT	DL92401009	1	X5-Synthetic plate	
1	DL69003270	1	Plastic plate	
2	DL69003152	2	Ridge	
3	DL07141044	8	Hexagon bolt	
4	DL08501028	8	Washer	
5	DL08131016	8	Safety nut	
65.05			Base Plate	

Field kits DL92401010 T94-Transport wheels, fails ave




Item	Part No.	Qty	Name	SN INFO
1	DL69003267	1	Tube	
2	DL06910171	1	Fastening clamp	
3	DL69003243	2	Axle	
5	DL06704548	2	Rubber tyre	
6	DL69040261	2	Washer	
7	DL73003044	2	Holder	
8	DL07140818	8	Hexagon bolt	
9	DL08510817	8	Washer	
10	DL07140824	2	Hexagon bolt	
11	DL69003242	1	Securing device	
52.16	-		Steering Handle	
65.05	-		Base Plate	


**Lubricants** Lubricants and operating substances



Item	Part No.	Qty	Name	SN INFO
1	4812074488	1	Dynapac engine oil 5 ltr	
1	4812074490	1	Dynapac engine oil 20 ltr.	
2	4812074494	1	Dynapac hydraulic oil 5 ltr	
2	4812074495	1	Dynapac hydraulic oil 20 ltr	

**10 Engine** DL69200056\_00\_010\_DRP20 Engine / Fitting Parts





Item	Part No.	Qty	Name	SN INFO
11.00	DL05747045_100 1E		Engine Parts List	
11.01	DLMOT019729_0		Crankcase	
11.02	DLMOT019730_0 0		Front Cover	
11.08	DLMOT019731_0		Cylinder Head	
11.09	DLMOT019732_0		Camshaft	
11.19	DLMOT019733_0		Crankshaft And Piston	
11.21	DLMOT019734_0		Fuel Tank	
11.22	DLMOT019735_0 0		Dry Air Filter	
11.25	DLMOT019736_0		Throttle Control	
11.26	DLMOT019737_0		Silencer	
11.31	DLMOT019738_0		Recoil Starter	
11.44	DLMOT019739_0		Covering	
11.46	DLMOT019740_0		Contact Breaker/Ign.Coil	
11.53	DLMOT019741_0		Carburetor	
12.12	DL92410086_00		Engine Carrier	
12.13	DL92410702_00		Engine	
19.07	DLEA002611_00		Centrifugal Clutch	


Engine / Fitting Parts DL05747045\_1001E Engine Parts List



11.00


Item	Part No.	Qty	Name	SN INFO
1	DL05747045	1	Four-stroke engine	

#### Engine / Fitting Parts DLMOT019729\_00 Crankcase




Item	Part No.	Qty	Name	SN INFO
1	DL05747378	1	Ball bearing,grooved	
2	DL05748553	1	Radial seal	
3	DL05748950	1	Governor / controller	
4	DL05748951	2	Weight	
5	DL05748952	1	Holder	
6	DL05747346	2	Pin	
7	DL05748953	1	Spool valve	
8	DL05748954	1	Shaft,governor	
9	DL05747180	2	Drain plug	
10	DL05747129	2	Gasket, oil drain	
11	DL05747233	1	Thrust disc	
12	DL05747377	1	Spring ring	
13	DL05747188	1	Loop ring	
14	DL05747379	1	Collar nut	
15	DL05747348	2	Washer	
16	DL05747349	1	Spring cotter	
17	DL05747380	2	Screw	
18	DL05748599	1	Oil pressure switch	

Engine / Fitting Parts DLMOT019730\_00 Front Cover




Item	Part No.	Qty	Name	SN INFO
1	DL05748955	1	Crank case cover	
2	DL05748553	1	Radial seal	
3	DL05114005	1	Ball bearing,grooved	
4	DL05747221	1	Gasket,crankcase	
5	DL05748601	1	Filler cap	
6	DL05748603	1	Gasket, oil dip stick	
7	DL05748602	1	Filler cap	
8	DL05748603	1	Gasket, oil dip stick	
9	DL05747389	2	Dowel pin	
10	DL05747390	6	Screw	

#### Engine / Fitting Parts DLMOT019731\_00 Cylinder Head




Item	Part No.	Qty	Name	SN INFO
1	DL05748940	1	Cylinder head	
2	DL05747212	1	Valve guide	
3	DL05747368	1	Circlip	
4	DL05747211	1	Valve guide	
5	DL05748941	1	Cylinder head gasket	
6	DL05748916	1	Cylinder head cover	
7	DL05747125	1	Valve cover gasket	
8	DL05747369	1	Ventilation pipe	
9	DL05747322	4	Hexagon bolt	
10	DL05747356	2	Stud	
11	DL05747370	2	Stud	
12	DL05747371	2	Dowel pin	
13	DL05748639	4	Hexagon bolt	
14	DL05748558	2	Hose clip	
15	DL05747282	1	Spark plug	
16	DL05748608	1	Spark plug spanner	

Engine / Fitting Parts DLMOT019732\_00 Camshaft




Item	Part No.	Qty	Name	SN INFO
1	DL05748920	1	Valve stem seal	
2	DL05748961	1	Camshaft	
3	DL05747139	1	Return spring	
4	DL05748962	2	Pushrod	
5	DL05747231	2	Rocker arm	
6	DL05747404	2	Tappet	
7	DL05749002	2	Journal	
8	DL05748963	1	Inlet valve	
9	DL05748964	1	Outlet valve	
10	DL05747345	2	Valve spring	
11	DL05749003	2	Valve plate	
12	DL05748965	1	Guide plate	
13	DL05747272	2	Bolt	
14	DL05747354	2	Adjustment nut	

Engine / Fitting Parts DLMOT019733\_00 Crankshaft And Piston




Item	Part No.	Qty	Name	SN INFO
1	DL05748932	1	Piston ring set	
2	DL05748957	1	Piston	
3	DL05748958	1	Floating wrist pin	
4	DL05748959	1	Conrod	
5	DL05748960	2	Conrod screw	
6	DL05747239	2	Spring ring	
7	DL05748619	1	Fitting key	
8	DL05747191	1	Woodruff key	
9	DL05747228	1	Fan	
10	DL05749001	1	Starting pulley	
11	DL05748622	1	Collar nut	

Engine / Fitting Parts DLMOT019734\_00 Fuel Tank




Item	Part No.	Qty	Name	SN INFO
1	DL05748938	1	Fuel tank	
2	DL05748592	1	Tank cover	
3	DL05748593	1	Gasket, tank cover	
4	DL05747464	1	Rubber,supporter	
5	DL05747161	1	Filter,fuel	
6	DL05748568	1	Hexagon bolt	
7	DL05747188	1	Loop ring	
8	DL05747312	2	Collar nut	
9	DL05748937	1	Fuel hose	
10	DL05748570	2	Hose clip	

Engine / Fitting Parts DLMOT019735\_00 Dry Air Filter




Item	Part No.	Qty	Name	SN INFO
1	DL83403043	1	Gasket	
2	DL05749004	1	Element,washable	
3	DL05747447	1	External filter	
4	DL05747163	1	Rubber grommet	
5	DL05748935	1	Filter cover	
6	DL05747183	2	Wing nut	
7	DL05748936	1	Knuckle tube	
8	DL05747312	2	Collar nut	
9	DL05747452	1	Screw	

Engine / Fitting Parts DLMOT019736\_00 Throttle Control




Item	Part No.	Qty	Name	SN INFO
1	DL05748897	1	Control assy.	
2	DL05748947	1	Lever,control	
3	DL05747227	1	Belleville spring	
4	DL05747155	1	Washer	
5	DL05747264	1	Safety nut	
6	DL05747156	1	Connecting piece	
7	DL05747158	1	Adjusting spring	
8	DL05747425	1	Screw	
9	DL05747341	1	Return spring	
10	DL05747333	1	Spring ring	
11	DL05747332	1	Wire holder	
12	DL05747334	1	Screw	
13	DL05747418	1	Cable clip	
14	DL05747426	1	Screw	
15	DL05747322	2	Hexagon bolt	
16	DL05748943	1	Arm governor	
17	DL05748944	1	Governor rod	
18	DL05748945	1	Governor spring	
19	DL05748946	1	Return spring	
20	DL05748997	1	Screw	
21	DL05747312	1	Collar nut	

#### Engine / Fitting Parts DLMOT019737\_00 Silencer




Item	Part No.	Qty	Name	SN INFO
1	DL05748911	1	Silencer	
2	DL05748912	1	Muffler guard	
3	DL05748624	1	Exhaust gasket	
4	DL05747355	1	Screw	
5	DL05747316	4	Self tapping screw	

#### Engine / Fitting Parts DLMOT019738\_00 Recoil Starter




Item	Part No.	Qty	Name	SN INFO
1	DL05749005	1	Recoil starter	
2	DL05747642	1	Starter housing	
3	DL05749006	1	Rope pulley	
4	DL05749007	2	Ratchet	
5	DL05748327	1	Friction spring	
6	DL05749008	1	Guide,ratchet	
7	DL05748329	1	Spring	
8	DL05747293	1	Return spring	
9	DL05749009	2	Return spring	
10	DL05748578	1	Starter rope	
11	DL05748579	1	Locking screw	
12	DL05747656	1	Handle	
13	DL05748331	3	Screw	
14	DL05748654	1	Label	

#### Engine / Fitting Parts DLMOT019739\_00 Covering




Item	Part No.	Qty	Name	SN INFO
1	DL05748925	1	Engine cover	
2	DL05748926	1	Side plate	
3	DL05749010	1	Cover	
4	DL05748627	1	Oil alarm unit	
5	DL05748628	1	Engine stop switch	
6	DL05747322	6	Hexagon bolt	
7	DL05747325	1	Screw	
8	DL05747648	1	Cable clip	
9	DL05747318	1	Screw	

Engine / Fitting Parts DLMOT019740\_00 Contact Breaker/Ign.Coil




Item	Part No.	Qty	Name	SN INFO
1	DL05748630	1	Coil,ignition	
2	DL05748631	1	Spark plug socket	
3	DL05749011	1	Shut down rope	
4	DL05747395	2	Screw	

#### Engine / Fitting Parts DLMOT019741\_00 Carburetor




Item	Part No.	Qty	Name	SN INFO
1	DL05749157	1	Carburetor	
2	DL05748898	1	Floater housing	
3	DL05748899	1	Screw plug with seal	
4	DL05747249	1	Kit,seal	
5	DL05748900	1	Screw plug with seal	
6	DL05748588	1	Float set	
7	DL05747146	1	Kit,floater valve	
8	DL05748583	1	Main nozzle	
9	DL05749159	1	Main nozzle, #65	
10	DL05749160	1	Main nozzle, #68	
11	DL05747148	1	Stop screw	
12	DL05749158	1	Main nozzle	
13	DL05748490	1	Gasket	
14	DL05747644	1	Kit, bolts	
15	DL05748905	1	Cap,filter	
16	DL05747645	1	Lever	
17	DL05747441	1	Fastening plate	
18	DL05747442	1	Spring	
19	DL05747218	1	Gasket	
20	DL05747313	1	Cup,fuel strainer	
21	DL05748500	2	Screw	
22	DL05747194	1	Kit,nozzle, #35	
23	DL05747159	1	Lever	
24	DL05747281	1	Dowel pin	
25	DL05748931	1	Insulator	
26	DL05747342	1	Insulator gasket	
27	DL05747440	1	Gasket, carburetor	
28	DL05747149	1	Connecting piece	

Engine / Fitting Parts DL92410086\_00 Engine Carrier




Item	Part No.	Qty	Name	SN INFO
1	DL69030332	1	Engine carrier	
2	DL06127525	4	Rubber buffer	
3	DL07231211	4	Socket-head cap screw	
4	DL08511324	4	Washer	
5	DL08241217	4	Domed cap nut	
6	DL08752130	4	Spring washer	
7	DL69030240	4	Shim	

#### Engine / Fitting Parts DL92410702\_00 Engine




Item	Part No.	Qty	Name	SN INFO
1	DL05747045	1	Four-stroke engine	
2	DL07590825	4	Pin screw	
3	DL08510817	4	Washer	
4	DL08130813	4	Safety nut	
5	DL69040357	1	Supporting plate	
6	DL07140824	1	Hexagon bolt	
7	DL08510817	2	Washer	
8	DL05650116	1	Centrifugal clutch	
9	DL07230838	1	Socket-head cap screw	
10	DL69040261	1	Washer	
11	DL92410583	1	V-belt	
12	DL69040401	1	V-belt guard	
13	DL07230847	4	Socket-head cap screw	
14	DL69040215	1	Double-ended union	
15	DL09331098	1	Sealing ring	
16	DL05546131	1	Screw plug with seal	
17	DL69040391	1	Hose	
18	DL05551409	1	Hose clip	
19	DL69040308	1	Holding rail	
20	DL69040362	1	Seal	
21	DL69040291	2	Sleeve	
22	DL07140824	2	Hexagon bolt	
23	DL09160406	5	Dowel pin	
24	DL08510817	2	Washer	
25	DL07010816	1	Hexagon bolt	
26	DL08500823	4	Round anchor plate	
27	DL08665000	4	Stop disc	
28	DL06510213	1	Plug	
29	DL23040147	1	Supporting plate	
30	DL08510817	1	Washer	
12.12		1	Engine Carrier	


#### Engine / Fitting Parts DLEA002611\_00 Centrifugal Clutch



Item	Part No.	Qty	Name	SN INFO
0	DL05650116	1	Centrifugal clutch	
1	DL05660177	1	Coupling housing	
2	DL05113305	2	Ball bearing,grooved	
3	DL09222500	1	Circlip,internal	
4	DL05660784	1	Circlip	
5	DL05660179	1	Coupling hub	
6	DL05660728	2	Centrifugal weight	
7	DL05660189	1	Repair Kit	
8	DL05660724	1	Cover disc	
9	DL05660731	2	Countersunk screw	
10	DL05660725	1	Cover disc	
11	DL09240055	1	Circlip,external	
12	DL05660181	1	Belt pulley	
13	DL05660183	3	Centrifugal weight	
14	DL05660185	1	Covering disc	
15	DL05660187	6	Countersunk screw	
16	DL05660188	1	Paste	


**20 Transmission** DL69200056\_00\_020\_DRP20 Power Transmission / Actuation






Item	Part No.	Qty	Name	SN INFO
27.01	DL69110044_02		Travel Actuation	
27.09	DL69100045_01		Throttle Control	
27.14	DL69110170_05		Steering rod head	
27.17	DL69110222_02		Detent, assembled	
29.08	DLEA002305_00		Actuat.Cable Throttle Re.	

#### Power Transmission / Actuation DL69110044\_02 Travel Actuation



Item	Part No.	Qty	Name	SN INFO
1	DL69110170	1	Steering rod head	
2	DL08510817	4	Washer	
3	DL07140824	4	Hexagon bolt	
4	DL05553192	1	Hose assy.ac.WN3111	


Power Transmission / Actuation DL69100045\_01 Throttle Control




Item	Part No.	Qty	Name	SN INFO
1	DL05561594	1	Throttle control	
2	DL07320508	2	Countersunk screw	
4	DL08510511	2	Washer	
5	DL08240510	2	Domed cap nut	
52.16			Steering Handle	
12.12			Engine Carrier	

#### Power Transmission / Actuation DL69110170\_05 Steering rod head

2) Anziehdrehmoment 25 Nm Tightening torque 25 Nm



# 27.14/1




1) mit Fett DL00996016 einsetzen insert with grease DL00996016

# 27.14/2

Item	Part No.	Qty	Name	SN INFO
1	DL69110178	1	Housing	
2	DL05546051	1	Screw plug with seal	
3	DL06245060	1	Sealing ring	
4	DL69110147	1	Sealing lid	
5	DL07230605	2	Socket-head cap screw	
6	DL05568996	1	Scraper	
7	DL06283067	1	Bushing	
8	DL05661358	1	Pressure spring	
10	DL69110354	1	Piston rod	
11	DL05802099	1	Piston seal	
12	DL69110168	1	Guide bush	
13	DL06220401	1	Loop ring	
14	DL69110169	1	Bushing	
15	DL06220530	1	Loop ring	
16	DL69110363	1	Flange	
17	DL08650817	4	Washer	
18	DL07230822	4	Socket-head cap screw	
19	DL05548022	1	Double-ended union	
20	DL69110123	1	Bolt	
21	DL69110122	1	Socket-head cap screw	
22	DL69110164	1	Handle	
23	DL07230822	6	Socket-head cap screw	
24	DL08650817	6	Washer	
25	DL69110190	1	Lever	
26	DL69110219	1	Driver	
27	DL07230623	2	Socket-head cap screw	
28	DL69110220	1	Driver	
29	DL06282084	1	Bushing	
30	DL69110222	1	Detent, assembled	
31	DL07230613	3	Socket-head cap screw	
32	DL69110188	1	Travel lever	
33	DL09160817	1	Dowel pin	
34	DL06270009	2	Wedge safety washer	

#### Power Transmission / Actuation DL69110222\_02 Detent, assembled


- 1) Gleitflächen zueinander zeigend Sliding surface face together
- 2) mit Fett DL00996016 einsetzen insert with grease DL00996016
- Muttern anziehen und kontern bis Haltemomente der Raste 25 +3 Nm betragen. tightend and lock the nuts to adjust the holding torque of the defend up to 25 +3 Nm.
- 4) Einbaulage der Teile beachten attend fitting position of the parts



# 27.17

Item	Part No.	Qty	Name	SN INFO
1	DL69110186	1	Flange	
2	DL06283093	1	Bushing	
3	DL69110221	1	Control shaft	
4	DL05586256	2	Stop disc	
5	DL06220183	1	Loop ring	
6	DL09126629	1	Pin,cylindric	
7	DL05340050	3	Ball	
8	DL69110199	1	Stop disc	
9	DL09290350	4	Belleville spring	
10	DL05520416	2	Supporting disc	
11	DL08121815	1	Hexagon nut	
12	DL05542918	1	Nut	


Power Transmission / Actuation DLEA002305\_00 Actuat.Cable Throttle Re.




29.08

Item	Part No.	Qty	Name	SN INFO
0	DL05561594	1	Throttle control	
1	DL05566582	1	Control box with lever	
2	DL05561582	1	Control	


**50 Frame** DL69200056\_00\_050\_DRP20 Frame with Attachment Parts






Item	Part No.	Qty	Name	SN INFO
52.16	DL92410087_00		Steering Handle	
53.28	DL92410577_00		Protection hood	
53.97	DL69120833_00		Single-point suspens.,assembled	

Frame with Attachment Parts DL92410087\_00 Steering Handle






52.16/2

Item	Part No.	Qty	Name	SN INFO
1	DL69060485	1	Console	
2	DL58160116	1	Wall duct	
3	DL07140824	2	Hexagon bolt	
4	DL08510817	2	Washer	
5	DL08621084	2	Washer	
6	DL07141027	4	Hexagon bolt	
7	DL08511021	4	Washer	
8	DL06142915	1	Stop buffer	
9	DL08110813	1	Hexangon nut	
10	DL08752084	1	Spring washer	
11	DL69440120	1	Seal	
12	DL07140824	2	Hexagon bolt	
13	DL08510817	2	Washer	
14	DL68110147	1	Sealing ring	
15	DL73060114	1	Threaded rod	
16	DL08141620	2	Hexagon nut	
17	DL06421265	1	Star knob	
18	DL06147115	1	Stop buffer	
19	DL69121033	1	Intermediate plate	
20	DL05756064	1	Wall duct	
21	DL69060273	1	Orifice	
22	DL07140629	4	Hexagon bolt	
23	DL08510612	4	Washer	
24	DL69060156	1	Sleeve	
25	DL08132026	1	Safety nut	
26	DL69121019	1	Cover	
27	DL69121020	1	Cover	
28	DL07140633	4	Hexagon bolt	
29	DL08621064	4	Washer	
30	DL08510612	4	Washer	
31	DL08130611	4	Safety nut	
32	DL69060527	1	Steering handle	
33	DL69060320	1	Lever	
34	DL07141641	1	Hexagon bolt	
35	DL09293152	1	Belleville spring	
36	DL08511730	2	Washer	
37	DL08131621	1	Safety nut	

Item	Part No.	Qty	Name	SN INFO
38	DL06140985	1	Stop buffer	
39	DL69060460	1	Holder,assembled	
39.1	DL69060206	1	Pillow block	
39.2	DL69060147	1	Flat steel	
39.3	DL07140665	2	Hexagon bolt	
39.4	DL08510612	2	Washer	
40	DL06151711	2	Rubber bush	
41	DL22040106	2	Bushing	
42	DL06282087	2	Bushing	
43	DL69060443	1	Threaded bolt	
44	DL08131621	1	Safety nut	
45	DL08511730	2	Washer	
12.12			Engine Carrier	


Frame with Attachment Parts DL92410577\_00 Protection hood



# 53.28


Item	Part No.	Qty	Name	SN INFO
1	DL69121009	1	Hood	
2	DL07141231	4	Hexagon bolt	
3	DL08511323	4	Washer	
4	DL69120778	1	Cover plate	
5	DL69120440	1	Strip steel	
6	DL07140641	2	Hexagon bolt	
7	DL08130611	2	Safety nut	
8	DL08510612	4	Washer	
9	DL69120853	1	Cover plate	
10	DL69120353	1	Strip steel	
11	DL07140641	2	Hexagon bolt	
12	DL08130611	2	Safety nut	
13	DL08510612	4	Washer	
12.12			Engine Carrier	

Frame with Attachment Parts DL69120833\_00 Single-point suspens.,assembled




Item	Part No.	Qty	Name	SN INFO
1	DL69120568	1	Single-point-lifting-dev.	
2	DL09293152	4	Belleville spring	
3	DL69120138	2	Holder	
4	DL09151615	2	Dowel pin	
5	DL08511730	4	Washer	
6	DL07131624	2	Hexagon bolt	
7	DL08131621	2	Safety nut	

**65 Plate** DL69200056\_00\_065\_DRP20 Plate / Foot




Item	Part No.	Qty	Name	SN INFO
65.05	DL69020045_02		Base Plate	
65.07	DL69020834_00		Base plate,assembled	


Plate / Foot DL69020045\_02 Base Plate



65.05/1



65.05/2




65.05/3

Item	Part No.	Qty	Name	SN INFO
1	DL69020834	1	Base plate,assembled	
2	DL07611215	1	Screw plug	
3	DL69020674	1	Exciter shaft	
7	DL69020753	1	Gear wheel	
8	DL09182820	1	Fitting key	
9	DL09213000	1	Circlip,external	
10	DL05222264	2	Cylinder roller bearing	
11	DL69020384	1	Cover	
12	DL07230806	4	Socket-head cap screw	
13	DL06220803	1	Loop ring	
14	DL69020746	1	Exciter shaft	
15	DL06283104	1	Bushing	
16	DL05428122	1	Inner ring	
17	DL69020670	1	Eccentric weight	
18	DL07231211	2	Socket-head cap screw	
19	DL69210174	2	Washer	
24	DL69020672	1	Gear wheel	
25	DL05114030	1	Ball bearing,grooved	
27	DL69020747	1	Bushing	
28	DL05222263	1	Cylinder roller bearing	
31	DL05222264	1	Cylinder roller bearing	
32	DL07611010	1	Screw plug	
33	DL69020707	1	Control shaft	
34	DL09223700	1	Circlip,internal	
35	DL09213000	1	Circlip,external	
36	DL05113700	1	Ball bearing,grooved	
37	DL68110170	1	Bushing	
38	DL05151010	1	Axial ball bearing	
39	DL07140532	1	Hexagon bolt	
40	DL08510511	1	Washer	
41	DL69020727	1	Piston	
42	DL06245052	2	Guiding band	
43	DL06245051	1	Piston seal	
44	DL08602603	1	Spring washer	
45	DL05520510	1	Shim	
46	DL09221130	1	Circlip,internal	
47	DL69020802	1	Pin,cylindric	

Item	Part No.	Qty	Name	SN INFO
64	DL69020367	1	Cylinder	
65	DL07230811	4	Socket-head cap screw	
66	DL06220852	1	Loop ring	
67	DL05548036	1	Double-ended union	
68	DL07140608	1	Hexagon bolt	
69	DL06210610	1	U-seal	
71	DL09312809	1	Radial seal	
73	DL06220803	2	Loop ring	
74	DL69020733	1	V-belt guard	
76	DL07140842	7	Hexagon bolt	
77	DL08510817	7	Washer	
81	DL69020479	1	V-belt pulley	
82	DL07230827	2	Socket-head cap screw	
83	DL09120862	1	Pin,cylindric	
84	DL69020304	2	Shim	
85	DL69020480	1	V-belt pulley	
86	DL07230834	2	Socket-head cap screw	
87	DL69020732	1	Cover	
89	DL07230811	5	Socket-head cap screw	
90	DL08752084	5	Spring washer	
91	DL69020253	1	Housing cover	
92	DL07140842	12	Hexagon bolt	
93	DL06270011	12	Spring washer	
106	DL06222657	1	Loop ring	
111	DL06143712	4	Stop buffer	
116	DL08621084	16	Washer	
117	DL69020718	3	Stop	
118	DL07230831	3	Socket-head cap screw	
119	DL06270011	3	Spring washer	
120	DL69020719	1	Stop	
121	DL07230831	1	Socket-head cap screw	
122	DL06270011	1	Spring washer	
123	DL08665000	5	Stop disc	
12.12			Engine Carrier	
194.08			Service kit	

Plate / Foot DL69020834\_00 Base plate,assembled



# 65.07

Item	Part No.	Qty	Name	SN INFO
1	DL69020812	1	Base plate	
3	DL69020685	2	Hood, cover	
3.1	DL69020686	1	Cover plate	
3.2	DL69020681	1	Foam	
3.3	DL69020682	1	Foam	
4	DL07140824	16	Hexagon bolt	
5	DL08621084	16	Washer	
6	DL07140814	8	Hexagon bolt	
7	DL08510817	8	Washer	

100 Accessories DL69200056\_00\_100\_DRP20 Accessories






**♦ DYNAPAC** 

Item	Part No.	Qty	Name	SN INFO
101.03	DL92410088_01		Decals	


Accessories DL92410088\_01 Decals



101.03


Item	Part No.	Qty	Name	SN INFO
1	DL92410302	1	Decal	
2	DL00832675	1	Decal,operation	
3	DL00830766	1	Decal,operation	
4	DL00830085	1	Decal,operation	
5	DL00832654	1	Decal,indication	
6	DL92410421	1	Type designation	
7	DL00832900	1	Decal,indication	
8	DL00832901	1	Decal,indication	
9	DL00833653	1	Decal,indication	
10	DL00831294	1	Decal,maintenance instr.	
11	DL00833833	1	Decal,indication	
12	DL00833968	1	Warning sign	

110 Options DL69200056\_00\_110\_DRP20 Special Equipment




Item	Part No.	Qty	Name	SN INFO
153.28	DL92400106_01		AD1-Protection hood	
165.01	DL92401009_00		X5-Synthetic plate	
166.03	DL92400107_00		T94-Transport wheels,failsave	
181.24	DL69070308_00		Central electric, assembled	
182.04	DL92401032_00		AZ4-Operating hourmeter	
194.08	DL92492442_01		Service kit	


Special Equipment DL92400106\_01 AD1-Protection hood



# 153.28/1



# 153.28/2




1) Anziehdrehmoment 6 Nm Tightening torque 6 Nm

# 153.28/3

Item	Part No.	Qty	Name	SN INFO
1	DL07141220	2	Hexagon bolt	
2	DL08511323	2	Washer	
3	DL69040450	1	Exhaust	
4	DL07230605	1	Socket-head cap screw	
5	DL08590617	1	Washer	
6	DL82040409	1	Tube	
7	DL69120519	1	Baffle	
8	DL08590617	1	Washer	
9	DL07140649	1	Hexagon bolt	
10	DL00652060	1.60	Sealing section	
11	DL69070308	1	Central electric, assembled	
12	DL07140629	4	Hexagon bolt	
13	DL08510612	4	Washer	
14	DL05551910	2	Tube clamp	
15	DL07140818	2	Hexagon bolt	
16	DL08510817	2	Washer	
17	DL08510612	1	Washer	
18	DL00833854	1	Decal,operation	
19	DL69120892	1	Hood	
20	DL69120833	1	Single-point suspens.,assembled	
21	DL07141224	2	Hexagon bolt	
22	DL08752130	2	Spring washer	
23	DL69120853	1	Cover plate	
24	DL69120353	1	Strip steel	
25	DL07140641	2	Hexagon bolt	
26	DL08510612	4	Washer	
27	DL08130611	2	Safety nut	
28	DL69120854	1	Cover plate	
29	DL69120440	1	Strip steel	
30	DL07140641	2	Hexagon bolt	
31	DL08510612	4	Washer	
32	DL08130611	2	Safety nut	
33	DL06140945	1	Stop buffer	
34	DL08510612	1	Washer	
12.12			Engine Carrier	
11.00			Four-stroke engine	
12.13			Engine	


Item	Part No.	Qty	Name	SN INFO
101.03			Decals	
53.28			Protection hood	
52.16			Steering Handle	

**Special Equipment** DL92400107\_00 T94-Transport wheels,failsave



Item	Part No.	Qty	Name	SN INFO
1	DL69003134	1	Tube	SN - from 101924641001 to 101924661010
1	DL69003267	1	Tube	SN - from 101924661011 ff.
2	DL06910171	1	Fastening clamp	
3	DL69003243	2	Axle	
5	DL06704548	2	Rubber tyre	
6	DL69040261	2	Washer	
7	DL73003044	2	Holder	
8	DL07140818	8	Hexagon bolt	
9	DL08510817	8	Washer	
10	DL07140824	2	Hexagon bolt	
11	DL69003242	1	Securing device	
52.16	-		Steering Handle	
65.05	-		Base Plate	


Special Equipment DL69070308\_00 Central electric, assembled



# 181.24

Item	Part No.	Qty	Name	SN INFO
1	DL69070202	1	Dash board	
2	DL05766777	1	Switch	
3	DL05768253	1	Hourmeter	
4	DL07210316	2	Pens head screw	
5	DL08510307	2	Washer	
6	DL69070212	1	Wire harness	

#### **Special Equipment** DL92401032\_00 AZ4-Operating hourmeter



# 182.04

Item	Part No.	Qty	Name	SN INFO
KIT	DL92401032	1	AZ4-Operating hourmeter	
1	DL05768253	1	Hourmeter	
2	DL69070283	1	Wire harness	
3	DL69070202	1	Dash board	
4	DL07210316	2	Pens head screw	
5	DL08510307	2	Washer	
6	DL06911047	5	Cable strap	

♦	DY	/N	A	PA	C
•	FROXT GROUP				

	Referenced Pages	
DL92401009_00 X5-Synthetic plate		

